

LINX-20x Automation Server, BACnet

Installation instructions

Instructions de montage






Montageanweisung



Montagevoorschrift


Istruzioni di montaggio

Instrucciones de montaje

Monteringsanvisning









Connectors			Status LEDs		
EIA-485	4	Input GND	A	Green	OPC client connected
MS/TP	5	Input + (B) non-inverting input		Green flashing	OPC activity
Modbus	6	Input - (A) inverting input	B	Green flashing fast	Traffic on BACnet MS/TP port
Ethernet	8	10/100Base-T (RJ45)	C	Green flashing	Traffic on BACnet/IP port
POWER	15	Power supply input EARTH GND	D	Green	Ethernet link
	16	Power supply input MINUS Can be connected to EARTH GND	E	Green flashing	Ethernet traffic
	17	Power supply input PLUS  Must NOT be connect to EARTH GND	F	Green	LINX-200:OFF LINX-201:BBMD enabled
SERIAL	40	EIA-232 (DB9 male) Terminal or M-Bus depending on DIP switch No. 7	G	Green	Power
			H	OFF	Normal operation

Buttons	
RESET	Reset
STATUS	Send "I AM" message

NOTE: If terminal 4 is not connected make a short between terminal 15 and 16, and connect to EARTH GND.

Serial Port



OFF
ON

Factory default, do not change!					
1	2	3	4	5	6
OFF	OFF	ON	OFF	OFF	OFF

7	Serial Port
OFF	Terminal Mode
ON	M-Bus Mode

MAC address of Ethernet port

Serial number of the device

