e-Touch Flexi 1R-5P

Electronic Intelligent Controls, S.L. Passatge Garrotxa, 6

08830 Sant Boi de Llobregat Barcelona, Spain

Tel.: +34 93 652 55 21 Fax: +34 93 652 55 22

www.e-controls.es info@e-controls.es

# Instruction sheet





# Multifunctional touch switch with 1 button, 5 touch zones and 1 led indicator

e-Touch Flexi is a multifunctional touch switch product family for lighting control, curtains and motorized blinds control or for any other control requirement in an installation. The touch keypads are completely customizable and it is possible to define the design of any pushbutton and any touch zone of the panel using the e-Touch Creator web page in www.e-controls.es, being able to combine any colour for the pushbutton with icons or texts that clearly define each touch

The e-Touch Flexi 1R-5P model consists of a single button with 5 touch zones that can be configured with any control function. The pushbutton includes a Led indicator to signal different

e-Touch Flexi is combined with any bus coupling unit of the e-Bus Coupling family products, that provides the necessary control for the desired communication protocol and is configured through the EConfigurator APP available for Android in Google Play Store.

#### Product description

The e-Touch Flexi touch switch allow to perform any lighting control function in an installation. like switch on, switch off, light dimming and scene control, with a simple press on any touch zone. Control of motorized curtains or motorized blinds is also possible through additional devices for

The e-Touch Flexi panels are connected through a connector located on the back side, to a bus designs: coupling unit, called e-Bus Coupling, that provides the communication protocol to the building management system. Different bus coupling units are available for the most used communication protocols for building automation, thus being able to combine any touch keypad with any bus

#### Keypad customization tailored to each project

Through the e-Touch Creator website in www.e-controls.es, it's possible to define the aesthetic of each of the pushbuttons, being possible to choose an icon or a text for each touch zone as well as the colour, for the pushbutton background and for the icon or text. It's also possible to

add images or pictures for every touch zone, making the device a completely flexible product and adaptable to any project.

Once the touch switch is finished, it's possible to send the design through a form to E-Controls for printing, or also download the design to print by anyone. The following examples show different









#### Function settings for each touch zone

This touch switch has 5 touch zones that can be configured with the desired function. Depending on the type of bus coupling unit selected, the touch switch can do some functions or others, based on the protocol selected and the functions defined in the communications standard of

In order to properly configure each touch zone it is necessary to know the number of each pushbutton. The following image shows the figures that define each touch zone:

- · If a DALI 2 bus coupling unit ref. BC.080001-001 or BC.582001-001 is selected to operate with a DALI controller, it is necessary to use manufacturer tool of the DALI controller to do the configuration of each pushbutton function. To do this, each pushbutton number will be used to assign to each instance of the DALI bus.
- · If a MASTER bus coupling unit is selected, like the model e-Bus Coupling DALI Master ref. BC.581002-001 or the model e-Bus Coupling 0-10V ref. BC.501001-001, it is necessary to use the APP EConfigurator tool to configure the functions of each touch zone.

#### Touch switch LED indicator functions


This touch switch has a single Led indicator centered on the key, that performs different functions depending on the type of bus coupling unit used.

The functions available for the Led indicator are:

- Pressing a key: When any of the 5 pushbuttons are pressed, the touch switch front led indicator lights up indicating that the pushbutton has been pressed.
- Correct initialization of the device: When de device powers up, the led indicator flashes briefly, indicating that the device is properly configured.
- Cleaning mode: When entering in cleaning mode, the led indicator flashed briefly every second during the 60 seconds cycle that lasts the cleaning mode.
- · Configuration conflict: The led indicator lights up permanently indicating that the bus coupling unit has been previously configured with another touch switch model. In this case it

must be reconfigured again for this touch switch model.

- Installation error: If a touch switch is configured for one bus coupling unit model and afterwards is connected to another bus coupling unit model, the led indicator will flash rapidly during 10 seconds at the moment of powering the device or every time that a touch zone is pressed, indicating an installation error. In this case, it must be reconfigured again or has to be connected to the correct bus coupling unit.
- Receiving a "Wink" command: The led indicator blinks at a rate of one second during 30 seconds. This case is relevant for a DALI bus coupling unit configured through a DALI



#### Proximity and brightness sensor

The touch switch includes a proximity and brightness sensor that provides different functions:

- · Auto switch off scene led: Depending on the bus coupling unit, it is possible to configure the led indicators to stay switched on to signal scenes or states. For this case it is possible to configure the led indicators to turn off automatically when the room becomes dark, to avoid disturbing them.
- · Cleaning mode function: The cleaning mode function allows you to lock the operating of the touch switch temporarily in order to clean the panel. To do this, the proximity sensor must be covered for 5 seconds with the finger until the led indicator 1 flashes. In this state the touch switch is locked during 60 seconds so it can be cleaned without sending commands.

#### General touch switch configuration functions

Through the APP EConfigurator of E-Controls and the NFC proximity wireless data transfer technology, it is possible to configure the device. To do this, download the APP from Google Play Store and install it in a mobile phone with an Android operating system.

The configuration parameters available on the device are:

1. Auto switch off scene leds: Enable / disable the auto switch off of the led indicator when the room becomes dark. By default this function is enabled.

The configuration of the touch switch can be done without powering the device, and even

without removing it from the packaging, making the configuration process extremely easy.

- 2. Cleaning mode: Enable / disable this function. By default this function is enabled.
- 3. Led intensity: Brightness level front led intensity can be adjusted between 0 and 100%. By
- 4. Touch switch sensitivity pushbuttons: Adjust the sensitivity of the touch zones between 4 possible values; low, medium, high, very high. By default is at high.

NOTE: In case if configuring the device powered, when bringing the phone near the device, some unwanted pushbutton press may be detected that interacts with the installation.

#### Product installation

NOTE: For the installation the bus coupling unit, read the instruction sheet of the device selected. Caution Disconnect the power supply of the bus coupling unit to which the touch switch will be

- Assemble the plastic frame on the touch switch paying attention that the ventilation slots are in the lower and upper left side.
- Clip the touch switch e-Touch Flexi into the holes of the front connector on the bus coupling unit, and press until the frame will be firmly fixed to the wall and pressed by the keypad.
- Apply supply power to the device and check the front led indicator flashes.
- Configure the device according to the bus coupling unit selected.
- Remove the front protective film of the device.

## Technical features

#### Touch switch consumption Touch switch + bus coupling unit selected NOTE: Current consumption with all sensors active, the led permanently turned on and sending DALI frames (does not apply to the e-Bus Coupling Modbus RS485 and e-Bus Coupling 0-10V).

#### Touch switch

Type
Number of buttons
Number of touch zones
Aesthetic
Custom design though e-Touch Creator website
LED indicators
Quantity
Colour
Functions LED brightness dimmable 0-1009
Temperature sensor
Sensor type Digita
Resolution
Measuring range
Humidity sensor (optional)
Sensor type Digita
Resolution
Measuring range
Wireless communication
Technology
Standard
Reading speed
Data security
Proximity sensor
Technology
Wavelength
Detection range

Disconnect the device from the power supply before mounting or moving it.

- Do not leave cables peeled or turned around the device.
- · Do not connect the device with the hands wet.
- · Do not open or hole the device.
- Keep the device and cables away from humidity and dust.
- · Clean the front cover with a water moisture soft cloth.

#### Brightness sensor Mechanical features

Front panel	 
Colour	 White or Black
Protection degree (assembled)	 
Temperature	
Operating	 °C to +50 °C (32 °F to 122 °F)

midity (no condensation) 

utomatic electrical controls for household and similar use EN 60730

# 

Marking	
Security	
Standard	
IEC protection	Class III
EMC	
Emission	61000-6-3
ImmunityEN	61000-6-1

### Ordering numbers

ouch Flexi 1R-5P White, touch switch 1 button, 5 touch zones, 1 led, white . . . . . TP.010500-000 

package of this product is considered as industrial packaging intended for professional use only. The manufacturer is not responsible of the incorrect installation or use of the product. Specifications are subject to change without notice.

